

The Spinder 'Cosmos' free stall divider is a prime example of an 'open' cubicle. Large and spacious: therefore very animal friendly. This open system provides room enough for the cow to move naturally, when getting up and laying down. Consequentially the cows will lay down sooner which will improve production and hoof health.

For matting we advise a cow mattress: the Spinder Meadow mattress or the FriesKo water bed. The combination Cosmos and loose bedding is also a possibility.

The PE retaining knee rail ensures for a perfect position of the animal, resulting in clean cows and cubicles.

Major characteristics:

- Exceptionally 'open' cubicle which allows the cow to move naturally, when getting up and laying down;
- Plenty head space;
- Simple and solid design;
- Neck rail: 120 cm;
- Widely applicable;
- Easy to install and adjust;
- Flexible and adjustable knee rail;

item-no.

01.15.500 Freestall divider model 'Cosmos' (mounting support piece and T-clamp included)

Fittings

11.11.240 Floor anchor M12 x 106 (4 per divider)

10.20.600 Tube 60 mm, length 6 m

04.21.020 Tube clamp coupling 60mm

04.24.020 End coupling 60 mm

11.06.200 Stopper 60 mm

01.15.550 Knee rail attachment PE125 for 'Cosmos', adjustable (1 per divider)

01.15.560 PE125 knee rail, length 1.00 Mtr. (stall width 110-115 cm)

01.15.561 PE125 knee rail, length 1.07 Mtr. (stall width from 115 cm)

01.15.565 PE125 knee rail, length 1.25 Mtr. (last knee rail, from divider to end wall)


01.90.370 End coupling for knee rail PE125 (attachment knee rail at end wall)

11.11.210 Floor anchor M10 x 71 mm (2 per end coupling)


01.15.590 Quick release for Cosmos

Model 'Cosmos' met kopboom en schoftboom


01.15.525 Model 'Cosmos' with head rail and neck rail
Connection for head rail four-way clamp incl. (1 per divider)




01.15.500
Model 'Cosmos'
for cows



Detail A




Detail B





01.15.500
Model 'Cosmos'
for cows,
single row at
outer wall

Stall width
110-120
center to center




Detail A




- Quick release for easy backdriving cow

01.15.500
Model 'Cosmos'
for cows,
single row,
unattached

Stall width
110-120
center to center



Detail B



item-no.	
01.15.500	Freestall divider model 'Cosmos' (mounting support piece and T-clamp included)
Fittings	
11.11.240	Floor anchor M12 x 106 (4 per divider)
10.20.600	Tube 60 mm, length 6 m
04.21.020	Tube clamp coupling 60 mm
04.24.020	End coupling 60 mm
01.15.550	Knee rail attachment PE125 for 'Cosmos', adjustable (1 per divider)
01.15.560	PE125 knee rail, length 1.00 Mtr. (stall width 110-115 cm)
01.15.561	PE125 knee rail, length 1.07 Mtr. (stall width from 115 cm)
01.15.565	PE125 knee rail, length 1.25 Mtr. (last knee rail, from divider to end wall)
01.90.370	End coupling for knee rail PE125 (attachment knee rail at end wall)
11.11.210	Floor anchor M10 x 71 mm (2 per end coupling)
01.15.590	Quick release for Cosmos
Model 'Cosmos' with head rail and neck rail	
01.15.525	Connection for head rail four-way clamp incl. (1 per divider)

